

HEG AUTOMOTIVE

FITTING INSTRUCTIONS

MAYKA Hose Reel

4 steps · Hex keys 6 mm and 5 mm

PARTS LIST

#	Part	Size	Used for
1	**Hose reel**		The reel itself
2	**Mounting block 1**	Triangular plate	Bolts to the reel
3	**Mounting block 2**	Bracket	Bolts to mounting block 1
4	**Hex socket screw**	M8 × 12	Joins the reel, block 1 and block 2
5	**Hex socket screw**	M6 × 18	Secures the assembly to the mounting channel
6	**Channel nut**	M6	Slides into the mounting channel
7	**Spring washer**	Ø6	Used with the M6 × 18 screws
8	**Flat washer**	Ø6 × 16 × 1.5	Used with the M6 × 18 screws

FITTING STEPS

1. **Attach block 1 to the reel**
   Bolt mounting block 1 (part 2) to the hose reel (part 1) using the M8 × 12 hex socket screws (part 4).

2. **Attach block 2 to block 1**
   Fit mounting block 2 (part 3) to mounting block 1, then tighten it down with more M8 × 12 screws (part 4).

3. **Place the channel nuts**
   Slide the two M6 channel nuts (part 6) into the mounting channel.

4. **Mount the reel**
   Line the assembled reel up with the channel nuts. Fasten it with the M6 × 18 hex socket screws (part 5), each fitted with a spring washer (part 7) and a flat washer (part 8), then tighten fully.

TOOLS NEEDED

You will need two hex (Allen) keys:

- **6 mm** — hex (Allen) key — M8 × 12 screws
- **5 mm** — hex (Allen) key — M6 × 18 screws